



INSTRUCTION MANUAL

EYELET CONNECTOR WITH POWER BOX MAX & SAE PLUG ADAPTER

PA01^{MAX}

ENGLISH _____ 3

FRANÇAIS _____ 4





FIND YOUR BATTERY

FIND YOUR CHARGER

Release 2026-01

PA01^{MAX} - BOX CONTENT



PA 01 MAX-EYELET CONNECTOR WITH POWER BOX MAX & SAE PLUG ADAPTER

THIS MANUAL CONTAINS IMPORTANT SAFETY AND OPERATING INSTRUCTIONS FOR PA01 MAX EYELET CONNECTOR WITH POWER BOX MAX & SAE PLUG ADAPTER

IMPORTANT SAFETY INSTRUCTIONS


Please read this manual and follow the instructions carefully before using the eyelet connector with Power Box MAX & SAE plug adapter.

WARNING

This connector provides a quick and secure way to either charge your battery with a charger or jump-start it using the Power Box MAX booster, thanks to its dual connection: an SAE plug and a dedicated Power Box MAX plug.

- We always recommend that you check the Battery Manufacturers specifications before using this charge cable extender.
- Explosive gases may escape from the battery during charging. Provide ventilation to prevent flames and sparks.
- For indoor use. Do not expose charger to rain, snow or liquids.
- Battery acid is corrosive. Rinse immediately with water if acid comes into contact with skin or eyes.
- Never charge a frozen battery.
- Never charge a damaged battery.
- Never place the charger on the battery while charging.
- Be extra cautious to reduce risk of dropping a metal tool onto battery. It might spark or short-circuit battery or other electrical part that may cause explosion.
- When working with a Lead Acid battery, remove personal metal items such as rings, bracelets, necklaces, watches...
- NEVER smoke or allow a spark or flame in vicinity of battery or engine.
- Do not charge non-rechargeable batteries.
- In order to reduce risk of electric shock, unplug charger from AC outlet before doing any. maintenance or cleaning. Turn off controls will reduce risk.
- The kit is not supposed to be used by children or by people who are not able to understand the manual, unless they are supervised by a responsible person who ensures the proper use of the kit.

FEATURES



* Compatible with any chargers equipped with SAE plug.

OPERATING INSTRUCTIONS


1. Connect the red eyelet to the positive battery terminal (+).
2. Connect the black eyelet to the negative battery terminal (-).

TO CHARGE THE BATTERY:

- Ⓐ First, connect the SAE adapter on the eyelet connector. Then plug, the other end into your compatible battery charger.

TO JUMP START THE BATTERY:

- Ⓑ Connect the Power Box MAX plug directly into the Power Box MAX booster.



SUITABLE FOR



COMPATIBILITY

BS 10 BS 15 BS 30 BS 30 MAX
BS 60 BK 20

Lead Acid						Lithium*
SLA	GEL	AGM	MF	DRY	Ca/Ca	LiFePO4

* Lithium batteries are only compatible with charging function (not with jump starting function).

CE MANUEL CONTIENT DES CONSIGNES IMPORTANTES DE SÉCURITÉ ET D'UTILISATION POUR VOTRE CONNECTEUR À OEILLET AVEC ADAPTATEUR POWER BOX MAX & SAE.


CONSIGNES DE SÉCURITÉ IMPORTANTES

Veuillez lire ce manuel et suivre attentivement les instructions avant d'utiliser le connecteur à œillet avec adaptateur POWERBOX MAX & SAE.

AVERTISSEMENT

- Ce connecteur offre un moyen rapide et sécurisé de recharger votre batterie à l'aide d'un chargeur ou de la démarrer à l'aide du booster Power Box MAX, grâce à sa double connexion : une prise SAE et une prise dédiée Power Box MAX.
- Nous vous recommandons toujours de vérifier les spécifications du fabricant de la batterie avant d'utiliser cette connexion permanente.
- Des gaz explosifs peuvent s'échapper de la batterie pendant la charge. Prévoyez une ventilation pour éviter les flammes et les étincelles.
- Pour une utilisation à l'intérieur. N'exposez pas le chargeur à la pluie, à la neige ou à des liquides.
- L'acide de la batterie est corrosif. Rincez immédiatement à l'eau si l'acide entre en contact avec la peau ou les yeux.
- Ne chargez jamais une batterie gelée.
- Ne chargez jamais une batterie endommagée.
- Ne posez jamais le chargeur sur la batterie pendant la charge.
- Soyez très prudent pour réduire le risque de faire tomber un outil métallique sur la batterie. Cela pourrait provoquer des étincelles ou un court-circuit, ce qui pourrait provoquer une explosion.
- Lorsque vous chargez une batterie au plomb, retirez vos objets personnels en métal tels que bagues, bracelets, colliers, montres...
- Ne JAMAIS fumer ou laisser une étincelle ou une flamme à proximité de la batterie, du chargeur ou de la connexion permanente.
- Ne pas charger des batteries non rechargeables.
- Afin de réduire les risques d'électrocution, débranchez le chargeur de la prise secteur avant d'effectuer tout entretien ou nettoyage.
- Ce connecteur n'est pas censé être utilisé par des enfants ou par des personnes qui ne sont pas en mesure de comprendre le manuel, à moins qu'ils ne soient supervisés par une personne responsable qui s'assure la bonne utilisation du chargeur.

CARACTÉRISTIQUES



* Compatible avec tous les chargeurs équipés d'une prise SAE.

MODE D'EMPLOI


1. Connecter l'œillet rouge à la borne positive (+) de la batterie.
2. Connecter l'œillet noir à la borne négative (-) de la batterie.

POUR CHARGER LA BATTERIE :

- Ⓐ Commencer par connecter l'adaptateur SAE au connecteur à œilletons.
Brancher ensuite l'autre extrémité à votre chargeur de batterie compatible.

POUR DÉMARRER LA BATTERIE :

- Ⓑ Connecter directement la prise Power Box MAX au booster Power Box MAX.



ADAPTER POUR



COMPATIBLE AVEC

BS 10 BS 15 BS 30 BS 30 MAX
BS 60 BK 20

Lead Acid						Lithium*
SLA	GEL	AGM	MF	DRY	Ca/Ca	LiFePO4

* Les batteries au lithium sont uniquement compatibles avec la fonction de recharge (et non avec la fonction de démarrage).

BATTERY FINDER



Find the right BS BATTERY for your vehicle
on our website

bs-battery.com

CHARGER SELECTION CHART



BATTERY TECHNOLOGY	AUTO-DETECT LEAD ACID & LITHIUM			LEAD ACID	
BATTERY VOLTAGE (V)	6 & 12	12	6 & 12	12	
BATTERY CAPACITY (Ah)	UP TO 20	UP TO 60	UP TO 40	UP TO 30	UP TO 120
BATTERY CAPACITY FOR MAINTENANCE (Ah)	UP TO 40	UP TO 120	UP TO 80	UP TO 60	UP TO 180
CHARGING CURRENT (A)	1	3	3x 2	1.5	1 - 4 - 6
CHARGING PROGRAM	9 STAGES		10 STAGES	8 STAGES	9 STAGES
RECONDITIONING FUNCTION	NO		YES	YES	
POWER SUPPLY FUNCTION	NO		YES	NO	
CAN BUS MODE	NO		YES	NO	
USERS TYPE	 FOR END-USERS		 FOR PROFESSIONALS	 FOR END-USERS	
GOOD TO KNOW	WALL MOUNT CONNECTION	MULTIAXIS HOOK	DISPLAY PARTS (OPTION page 58)	MULTIAXIS HOOK	WALL MOUNT FIXATION
SUITABLE FOR					